

TIME CHANGE FOR
SAMSUNG PROSTAR 816

WITH THE HANDSET HUNG UP

1. # 20
2. 1234
3. 1
4. #
5. #
6. 55
7. YY - YEAR
 08 [LAST TWO DIGITS OF YEAR]
MM = MONTH
 01 = JAN
 02 = FEB
 03 = MARCH
 04 = APRIL
 05 = MAY
 06 = JUNE
 07 = JULY
 08 = AUG
 09 = SEPT
 10 = OCT
 11 = NOV
 12 = DEC
DD = DAY OF MONTH
 01-31
W = DAY OF WEEK
 1 = MON
 2 = TUE
 3 = WED
 4 = THUR
 5 = FRI
 6 = SAT
 7 = SUN
HH = HOUR
 0100 - 2400 [MILITARY TIME]
MM = MINUTES
 00-59
8. #